Federal Communications Commission (FCC) Radio Frequency Interference Statement Warning

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

Information to the User

This equipment must be installed and used in strict accordance with the manufacturer's instructions. However, there is no guarantee that interference to radio communications will not occur in a particular commercial installation. If this equipment does cause interference, which can be determined by turning the equipment off and on, the user is encouraged to contact CognitiveTPG immediately.

Cognitive TPG is not responsible for any radio or television interference caused by unauthorized modification of this equipment or the substitution or attachment of connecting cables and equipment other than those specified by TPG, Inc. The correction of interferences caused by such unauthorized modification, substitution or attachment will be the responsibility of the user.

In order to ensure compliance with the Product Safety, FCC and CE marking requirements, you must use the power supply, power cord, and interface cable which are sold for use with this product or which meet the following parameters:

Power Suppl

UL Listed (QQGQ), Class 2 power supply with SELV (Secondary Extra Low Voltage), non-energy hazard output, limited energy source, input rated 100-240 Vac, 1.5/0.8 A, 50/60 Hz, output rated 24 Vdc, 2.3 A for 55 watt unit; 100-240 Vac, 2.0A, 50/60 Hz, output rate 24 Vdc, 3.125 A for 75 watt unit.

Use of this product with a power supply other than the CognitiveTPG power supply will require you to test the power supply and CognitiveTPG printer for FCC and CE mark certification.

Communication Interface Cable

A shielded (360 degree) interface cable must be used with this product. The shield must be connected to the frame or earth ground connection or earth ground reference at EACH end of the cable.

Use of a cable other than described here will require that you test the cable with the CognitiveTPG printer and your system for FCC and CE mark certification.

Power Cord

A UL listed, detachable power cord must be used. For applications where the power supply module may be mounted on the floor, a power cord with Type SJT marking must be used. For applications outside the US, power cords which meet the particular country's certification and application requirements should be used.

Use of a power cord other than described here may result in a violation of safety certifications which are in force in the country of use.

Industry Canada (IC) Radio Frequency Interference Statement

This Class A digital apparatus meets all requirements of the Canadian Interference-Causing Equipment Regulations. Cet appareil numérique de la classe A respecte toutes les exigences du Règlement sur le matériel brouilleur du Canada.

Voluntary Control Council for Interference (VCCI) Radio Frequency Interference Statement

This is a Class A product based on the standard of the Voluntary Control Council for Interference by Information Technology Equipment (VCCI). If this equipment is used in a domestic environment, radio disturbance may arise. When such trouble occurs, the user may be required to take corrective actions.

Disclaime

Information in this document is subject to change without notice. Consult your CognitiveTPG sales representative for information that is applicable and current. CognitiveTPG reserves the right to improve products as new technology, components, software, and firmware become available.

No part of this document may be reproduced, transmitted, or translated in any form or by any means, electronic or mechanical, for any purpose without the express written permission of CognitiveTPG.

Copyright

Copyright © 2009 by TPG IPB, Inc., 950 Danby Road, Ithaca, New York 14850, USA. All rights reserved. Printed in USA. Confidential, Unpublished. Property of TPG IPB, Inc.

Trademarks

CognitiveTPG[™] is a trademark of TPG IPB, Inc.

Microsoft, Windows NT are registered Trademarks of Microsoft Corporation in the U.S.A. and/or other countries. Inside Out Networks, Inside Out, EPIC, and Edgeport are trademarks of Inside Out Networks.

All other trademarks and registered trademarks are the property of their respective holders.

Website

http://www.CognitiveTPG.com

A798 Thermal Receipt Printer Setup Guide

Thank you for selecting **CognitiveTPG Model A798** Monochrome Single Station Thermal POS Receipt Printer

WORLD CLASS PRINTING... AND VALUE!


You have chosen the industry's best value in receipt printers. A798 combines sharp, high speed monochrome printing with unsurpassed durability.

Please review this Setup Guide and follow the prompts on the installation CD. Additional information can be found in the A798 User Guide and A798 Programmer Guide, which are included on the disk. If you have any questions, please call us at **800-732-8950** or **607-274-2500** or visit **www.CognitiveTPG.com**. Please visit the website to register your printer and provide feedback on its quality.

Setting up the printer (Pages referenced are from the User Guide)

Unpack the printer, saving all packing materials for future shipping or storage (page 11).

2 Load the roll of paper (page 12).



Made under one or more of the following U.S. patents: 4886381, 5579043, 5613787, 5651624, 5713678, 5752779, 5789916, 5800080, 5879090, 5887999, 5975776, 6027266, 6085973, 6089450, 6129465, 6155483, 6404452, 6486902, 6504331, 5749277, 6722754, 6739773, 6784909. Other U.S. and international patents pending.




A798 - SUG0001 Rev. C 11/09 Printed in the USA


Choose a location for the printer.

Connect the following cables based on your configuration, using a-b below.


When using USB (step "b" below), use caution to ensure the USB cable is connected to the USB connector on the back left of the printer and not into the cash drawer connector that is on the right back of the printer.



- a Cash drawer (if your installation includes this feature, page 15).
- 9-pin or 25 pin Serial or USB cable (serial: page 16; USB: page 17).
- Connect the power cable (page 18).
- Route cables as shown for your setup configuration (page 19).



Run a diagnostic test (page 19).



Configure the printer if necessary (page 20).

*** A798 - Diagnostics Form ***

Model number : A798-720D-TD00 Serial number : C073400014

Boot Firmware

Revision : V1.00 CRC : 08D3 P/N : 189-7940154A

Flash Firmware
Revision : V1.00
CRC : D70C

P/N : 189-7940155A

H/W parameters

Flash Memoriv Size 2 Mbytes 1152 kbytes Flash Logos/Fonts Flash User Storage 64 kbytes Flash Journal Size 64 kbytes SRAM Size 128 kbytes CPU Clock Fred 50 MHz Head setting Pre-Heating Disabled Print Density 100% 150 mm/sec Max Speed Paper Width 80 mm Max Power 55 W Knife Enabled Partial Cut 125 steps Paper Low Sensor Disabled

Comm. Interface

USB Driver Type : Printer
USB Packet w/Error : Reject

Resident Code Pages : 437, 850, 852, 857, 858

860, 863, 865, 866 1252, 862, 737, 874

A715 CP850 Emulation : Disabled

Logo(s) defined : YES User Char(s) defined : NO

Journal Unused : 64 kbytes

To enter Printer Config Menu

1) Flip DIP switch #1 down

Reset the printer, while holding the Paper Feed button down

Select a sub-menu:

 - EXIT
 -> 1 click

 - Print Current Configuration
 -> 2 clicks

 - Set Communication Interface
 -> 3 clicks

 - Set Diagnostics Modes
 -> 4 clicks

 - Set Emulation/Software Options
 -> 5 clicks

 - Set Hardware Options
 -> 6 clicks

 - Set Paper Type
 -> 7 clicks

Enter code, then hold Button DOWN at least 1 second to validate

When the printer is configured for USB, this location will show either: "USB Driver Type: Native", "USB Driver Type: Printer Class", or "USB Driver: Comm Class".

Print Test and Configuration Menu Sample.

Samples will vary depending on the printer model.

DECLARATION OF CONFORMITY

Type of Equipment: Information Technology Equipment – Printer

Model: A798-XXXX-XXXX

Model: A799-XXXX-XXXX (X = any alphanumeric character)

Applicable EU Directives:

2004/108/EC (electromagnetic compatibility directive) 2006/95/EC (low voltage directive for product safety)

Harmonized Standards:

EN 55024 (1998/A1:2001/A2:2003) Information Technology Equipment Immunity Characteristics

EN 55022 (1998/A1:2000/A2:2003) EMC, Class A, Limits and Methods of Measurement of Interference

Characteristics of IT Equipment

IEC 60950-1 (2005) Second Edition - Product Safety Standard.

"TPG IPB, Inc., 950 Danby Road, Ithaca, New York, 14850, declares that the equipment specified above conforms to the referenced EU Directives and Harmonized Standards."

Rash Belleh

Date: Feb 6, 2009

Randy Bullock, Regulatory Compliance Engineer, CognitiveTPG and TPG IPB Ref #: 189-1300058 Rev C